Emergency Spill Kit Instructions

1- Protect Yourself- Put on safety goggles and gloves

2- Immediately Contain the Spill

Small spills:

Cover the spill with Absorbent Pads and/ or QuiKleen Absorbent granules and allow them to soak up the fluid, then place used material in Disposal Bag.

Large spills:

Surround the spill with Absorbent Socks being sure to protect drains, grates or waterways. Place remaining Absorbent Pads and/ or QuiKleen Absorbent granules within the boom area to absorb the spilled fluid. Clean up spill by working from the outside of the spill toward the center to minimize spread of contamination.

3- Stop the Source

Stop the leak using the Repair Patch

Repair Patch Instructions

- Remove the release liner and place tape over desired repair area. Tape cannot be repositioned once applied
- Rub entire surface of the tape aggressively, especially the edges. Smooth the patch from the center to outer edges - Hold the patch in place for 2 minutes to ensure good adhesion.

Not for use under pressure or automotive applications under the hood. May not adhere to silicone or water-repellent materials. Tape must make complete contact with surface to properly seal.

4- Clean Up/ Disposal

Once absorbent materials are saturated and the spill has been completely absorbed, place used sorbents in the Disposal Bag and dispose of properly. Disposal of this waste may be governed by federal, state, and local regulations depending on the fluid spilled and amount.

** Acids need to be neutralized and disposed of properly **

** QuiKleen Absorbent CANNOT be used with Hydrofluoric Acid **